

Using the Automatic Timer

1. To switch on, press the **BLACK button** on the right hand side of the unit.
2. Select the correct race programme by pressing the **WHITE button** until the programme number you want is displayed.

Programme	Countdown sequence				Typical use	
One	3	2	1	0	Then repeats the complete 3 2 1 0 sequence until stopped (see below)	Fleet Races on Sundays
Two	5	4	1	0	Then every minute until stopped	Pursuit Races
Three	5	4	1	0		Single Fleet Start
Four	5	4	1	0	Then repeats the 5 4 1 0 sequence until stopped	Multiple Fleet Starts

3. Press the **RED button to set up for the start sequence**. The clock will show the countdown time PLUS 10 seconds.
4. Press the **RED button to start the sequence. Listen to the beeps. After ten seconds, put the class flag up with the first horn sound.**
5. **Stop the countdown at anytime by pressing the RED and WHITE buttons together.** The horn will stop working but the stopwatch will continue if the race has started. The only way to stop the stopwatch once it has started is to switch off the unit. **IF YOU SWITCH OFF THE UNIT ONCE YOU HAVE STARTED A RACE, THE TIMING WILL BE LOST!**
6. **Pressing the ORANGE button at anytime will sound the horn but does not affect the timer in any way.** This is useful for individual recalls, shortening the course etc.
7. **The push button on the extension cable is ONLY used for FINISHING a race. Press the button as each boat crosses the line.**
8. The unit records the times of each of the finishers. These can be played back later (as long as the unit has not been switched off). To play back the recorded times press and hold the top **GREEN button** for 5 seconds. The unit will enter Playback Mode. Once in Playback Mode you can only switch the unit off and restart the unit.
9. In Playback Mode press the **GREEN button** again to advance through the recorded times (up to 80 results are recorded). Pressing the **BLUE button** will go backwards through the count.
10. If you are unsure how to operate the unit, please speak to the Coxswains, Ian Castle, Rob Jackson or Chris Harris.